

D

С

В

Α

172-0136 REV I

PROPRIETARY AND CONFIDENTIAL


THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF DYTRAN INSTRUMENTS INC. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF DYTRAN INSTRUMENTS INC. IS PROHIBITED


1. FIRMLY HOLD MOLDED STRAIN **RELIEF TO PREVENT CONNECTOR** PLUG FROM TURNING.


3


- 2. WHILE HOLDING STRAIN RELIEF, ALIGN CONNECTOR PLUG TO **RECEPTACLE AND PUSH TO** ENGAGE.
- 3. TURN COUPLING NUT IN **CLOCKWISE DIRECTION UNTIL** CONNECTOR IS FULLY COUPLED WITH SENSOR.
- 4. TO DECOUPLE FROM SENSOR, HOLD MOLDED STRAIN RELIEF AND TURN COUPLING NUT COUNTER-CLOCKWISE. PULL STRAIN RELIEF.


NOTE: DO NOT ROTATE SENSOR TO COUPLE/DECOUPLE. THIS CAN DAMAGE THE PINS AND POSSIBLY BREAK THEM.











4

2 DWG NO 127-6418A 2 REV C